



-6-

ES:

ontal Coordinate System:
American Datum of 1983 (NAD83), projected to the State Plane
Coordinate System (SPCS) Louisiana South Zone. Distance units in U.S. Survey Feet.

Vertical Datum:
Elevations are shown in feet and indicate depths below Low Water Reference Plane 2007 (NAVD).
Distances on the Mississippi River, above and below Head of Passes are shown
in miles and kilometers.

Location of navigation aids are base on and provided by the U.S. Coast Guard and USACE crew.

Aerial Photography data source: NAIP, USDA-FSA-A

gence is N.O.A.A. Navigation Chart No. 11370.
allest Sounding per Quarter per Reach.
igh frequency (200 kHz) survey data represents the first signal return at a sounding
on and will include suspended solids, known as "fluff", if present. Low frequency (20 kHz)
y data normally penetrates through this "fluff" layer to depict elevations of consolidated bottom
al. Low frequency accuracies may vary depending on channel conditions and fathometer
s.

Sheet Reference Number

Revision Number:
4.0-201907022