


Distribution Liability: The data represents the results of data collection... The user is responsible for the results... Data Constants: Hydrographic survey data is subject to change...

Table with columns: Submitted, Recommended, Checked, Approved. Values include JTB & DBD, RSL, MSK.


MISSISSIPPI RIVER - B.R. TO GULF SOUTHWEST PASS - SHEET 4 SW_04_SWP_20190723_CS 23 July 2019



LEGEND table with symbols for Federal Navigation Channel, Cable Area, Borrow Area, Shoalest Sounding, Beacon, Red Navigation Buoy, Green Navigation Buoy, Anchorage Area, Obstruction Point, Wrecks-Submerged, and Project Depth Contour.



Gage Reading: 2.2 MLLW @ PILOT TOWN @ 0945 Sea Conditions: CHOPPY SEAS Vessel Name: JOHN BOPP Survey Type: CONDITION, SB Sounding Frequency***: LOW



NOTES: Horizontal Coordinate System: North American Datum of 1983 (NAD83)... Vertical Datum: Soundings are shown in feet and indicate depths below Mean Lower Low Water (MLLW, 07-11)...

Sheet Reference Number 4 of 13

Revision Number: 3.13-20160811